

# Installation of Speedy Dialer Pro

Do **NOT** connect your Speedy Dialer Pro hardware until the software has been installed.

## Step 1: Install Cheetah or Rapid Rabbit software CD in your desktop or laptop PC (Windows XP or Vista or 7).



The installation program should automatically start. If it does not, click **Start** in your PC's task bar, then click **Run**. Next, type **D:\AUTORUN.EXE** and press **<ENTER>**. (If the CD-Rom's drive letter is not **D**, substitute the appropriate drive letter).



One of these icons will appear on your PC desktop:  
**Cheetah Power Seller** or **Rapid Rabbit Auto Dialer**



## Step 2: Install the Speedy Dialer Pro hardware.

Follow steps  
A, B, C, D.  
**Step B has  
2 options.**

### A: PC Audio

Plug the **black** jack into the jack on the back of the Speedy Dialer Pro. (Push it in firmly to seat it properly.) Then plug the **pink** jack (microphone) and the **green** jack (speaker) into your

### Headset (choose your type)

#### B: (Back) Telephone Headset

Plug your telephone handset jack into the RJ9 jack on the back of the Speedy Dialer Pro.  
...or...

#### B: (Front) 2.5mm Headset

Plug your 2.5mm jack into the front of the Speedy Dialer Pro.




### C: Telephone Line

Plug the telephone cable from the wall into the RJ11 jack on back of the Speedy Dialer Pro.



### D: USB Port

Plug the mini-USB jack into the Back Front of the Speedy Dialer Pro and plug the standard USB jack into the USB port of your PC.

After finishing the above 2 steps, you should see a green  status light in the front of your Speedy Dialer Pro, indicating that it is ready to use. If you do not see a green light, unplug the USB jack from your PC, wait about 5 seconds, then plug it in again. If you still do not see a green light, try another USB port.

We want to help you if you have any problems! Call 972-248-0341 or go to [www.tellacom.net](http://www.tellacom.net)